Measures Explorer

FLOOD MEASURES:

Physical Infrastructure

Levees	along shorelines to prevent flooding. Le overflow of flood waters or in coastal a	e of earthen embankments or fill placed evees are used along rivers to prevent reas to protect against storm surge. Levees ent uses, such as roadways and walkways.
SHORELINE LOCATION:	DESIGN LIFE 75+ years	IMPACT ON THE WATERFRONT Major Intervention
Upland	ADAPTABILITY Varies	CONSTRUCTION COST TBD
COASTAL FLOOD IMPACTS MITIGATED:		
Sea Level Rise Storm Su	r ge Groundwater	Waves Erosion
Types of Levees:		
Earthen Levee	Raised Roadway	Raised Pathway

